

West Bloomfield Fire Department Tractor Pull

(Blacktop Pull)

West Bloomfield WI.

September 19 2009

Start Time 11:00 am

Registration and Weight Scale will be open at 8:00am

Farm Classes may register until 2:00pm

All other classes may register until the start of the class they wish to pull in

Rules may only be Contested at Driver's Meeting Before Pull

CLASSES

Pure Stock Classes(1957 And Older)

Paced At 3.5 mph, 20" Drawbar

3200, 4000, 5000, 6000,7000 and 7600

Max Tire Size:

3000 ---- 13.6" x 38"

4000 ---- 15.5" x 38"

5000 ---- 15.5 "x 38"

6000 - 7600 ---- 16.9" x 38"

Antique Classes (1955 And Older)

Paced at 4.0 mph, 20" Drawbar

3500, 4200, 4700, 5500, 6500 and 7500

Max Tire Size:

3500 -- 4700 --- 14.9" x 38" or 15.5" x 38"

5500 --- 16.9" x 38"

6500 -- 7500 --- 18.4" x 38"

Open Antique Classes (1955 and Older)

Paced at 7.0 mph, 20" Drawbar

3750, 4250, 4750, 5750, 6750 and 7750

Max Tire Size: All Classes --- 18.4" x 38"

No Oliver 88, Massy 44, Farmall M, MM U, or UB in 3750 Or 4250 classes

Farm Classes (Any Age)

Paced At 8.0 mph, 20" Drawbar

7800, 8300, 8800, 9800, 10300 and 10800

No Tire Limits

Information Call Dennis At 920-249-0295

Team Pull Classes

Paced At 4.0 mph, 20" Drawbar

8000, 10,000, 12,000

CLASS JUMPING:

There Will Be No Class Jumping

Antique Pull Antique Classes, Open Antique Pull Open Antique Classes, Pure Stock Pull Pure Stock Classes and Farm Pull Farm Classes

General Rules For All Pullers

1. **All Contestants enter at their own risk. SAFTY IS #1 PRIORITY OVER ALL RULES!**
2. Drivers ages 14 –18 must have written permission from their parent or legal guardian, and present their farm safety course certification. No one under the age of 14 may enter. **Drivers Must Be 18 Years Of Age Or Older In Antique, Open Antique And Farm**
3. Drivers must remain in tractor seat at all times, and operate the tractor in a safe manner at all times on and off the track. Think of safety of yourself and others.
4. Kill switches, wheelie bars and fenders are recommended in Open Antique, Antique and Farm. Wheelie bars must strong to hold the tractor.
5. No pressurized fuel tanks are allowed. LP gas tanks certified for LP gas are allowed
6. **All tractors will be flagged to stop when the front wheels reach 24" off the track if not equipped with wheelie bars.**
7. All tires must be on the tractor. Tires may be mounted forwards or backwards. No tracks, duals or chains allowed.
8. **All tractors must re-weigh and have hitch height checked before hooking to eliminator. Nothing may be added or taken off the tractor after you are officially weighted-in.**
9. The pull will start with a tight hook up with no jerks.
10. If anything falls off the tractor while hooked to the eliminator, the tractor will be disqualified.
11. All tractors must be in neutral while hooking up.
12. **The officials have the right to stop any entry at any time during the pull, and reserve the right to disqualify or deny entry at any time. The official has the final word, with no exceptions.**
13. The pull shall be considered over when the forward motion of the load stops.
14. Any tractor violating the track boundary will be measured from that distance if driver stops when flagged.
15. Tractors must be equipped with a 2 ½" clevis or pulling eye. Absolutely NO floating drawbars will be allowed in any classes. All hitches must be solid in all directions. **No bracing to drawbar behind rear cast of tractor above the point of hook.**
16. No T.A. or Power Shifting except in Farm Classes.
17. Only one hook per tractor per class.
18. Drivers may not consume any alcohol while operating any tractor.
19. All drivers should be in line and ready to pull at the start of their weight class.
20. Rules made at the Drivers Meeting take priority over any printed rules for the event.
21. Classes may be added or subtracted on the day of the pull.
22. **ANY PERSON CAUGHT TAMPERING WITH ANOTHER PULLER'S TRACTOR, WITHOUT THEIR CONSENT, WILL BE BANNED FROM THE PULL AND WELL FORFET ANY ENTRY FEES.**
23. **Officials Rulings Are Final**

Additional Rules For Pure Stock Classes

1. The age of the tractor must be 1957 or older.
2. HP & RPM: May not be more than 10% over the factory HP or RPM according to the serial number of the tractor and according to the Nebraska Test. Any tractor with more than 10% over the factory HP or RPM will be disqualified. A working PTO must be installed on the tractor, an unaltered positive throttle stop, and a working governor also mandatory.
3. Tractor must have stock model block, carburetor and serial number for the make and model of the tractor.
4. No front cut tires allowed
5. Tractors must run only on stock fuel designed for that tractor.
6. Tractors pulling in low gear must verify low gear to track officials. John Deere's with creeper low gear may pull in second gear and will be paced with a horn at 3.5mph.
7. Weights should be fastened to the tractor and any safe way, including weight brackets. No weights may be added in front of front casting or 24" behind the center of the rear axle.
8. No stripping of tractors below the dry shipping weight from the factory..
- 9 Stock draw bar.
- 10 **All other general rules apply.**

Additional Rules For Antique Classes

1. Age of tractor must be 1955 or older.
2. HP & RPM- Recommended HP may not exceed 15HP above weight class. Any qualifying tractor with 100Hp or over should pull in open.
3. No front cut tires allowed.
4. Weight may extend forward, no more than 24" in front of the tractor casting or 24" behind the center of the rear axle. Weights should be fastened safely.
5. Antique tractors must have a stock block for the make and model of tractor. No 12 ported heads, M-M 800 parts, or alcohol fuel will be allowed. Officials will test for alcohol in fuel.
6. **All other general rules apply.**

Additional Rules For Open Antique Classes

1. The age of the tractor must be 1955 or older.
2. **All drivers must be 18 years of age.**
3. HP & RPM—Any horsepower is allowed. If RPM exceed twice factory specifications, then safety equipment such as a bell housing blanket or flywheel wrap are highly recommended. A working governor and a dead-mans throttle are highly recommended. In the opinion of the track officials, any tractor operating unsafely will be disqualified.
4. Front cut tires are allowed in these classes only.
5. Weight may extend forward, no more than 24" in front of the tractor casting, or 24" behind the center of the rear axel. Weights should be fastened safely.
6. Tractor must have a stock block for that make and model of tractor. No alcohol or nitrous gas will be allowed. Officials will test and check for alcohol or nitrous fuel injection. Any puller caught using either will be disqualified from all classes.
7. **All other general rules apply.**

Additional Rules For Farm Classes

1. Tractors may be of any age.
2. **All drivers must be 16 years of age, and must present their farm safety course certification if under 18.**
3. No front cut tires are allowed.
4. Weight may extend forward, no more than 24" in front of tractor casting, or 24" behind the center of the rear axel. Weights should be fastened safely. A 12" wide opening must be left for hooking the chain to the drawbar.
5. Tractor must hook off belly mount drawbar in stock location.
6. Wheelie bars, kill switches and dead-man throttles are highly recommended in all farm classes.
7. **All other general rules apply.**

Order Of Pull

1. 3200# Pure Stock
2. 3500# Antique
3. 3750# Open Antique
4. 4000# Pure Stock
5. 8000# Team Pull
6. 4200# Antique
7. 4250# Open Antique
8. 4700# Antique
9. 4750# Open Antique
10. 5000# Pure Stock
11. 10000# Team Pull
12. 5500# Antique
13. 5750# Open Antique
14. 6000# Pure Stock
15. 12000# Team Pull
16. 6500# Antique
17. 6750# Open Antique
18. 7000# Pure Stock
19. 7500# Antique
20. 7600# Pure Stock
21. 7750# Open Antique
22. 7800# Farm
23. 8300# Farm
24. 8800# Farm
25. 9800# Farm
26. 10300# Farm
27. 10800# Farm